



BlueRinse Liner (01-08-011)

Fitting Instructions

DribblePot BlueRinse Liners separate solids and dose the water with Mudtech pH Blue, correcting filtered water pH to safe levels for handling and discharge. Helpful when dealing with smaller quantities of washwater arising from concrete, cement and grouting activities.



1. Drop BlueRinse Liner into DribblePot.



2. Align corners with the baskets corners.



3. Push corner over so it grips the basket.



4. Repeat on all corners.